

Figure 1: Design

```

android:layout_height="fill_parent">
<TextView android:layout_width="fill_parent"
    android:layout_height="wrap_content"
    android:text="@string/app_title" android:gravity="center"
    android:padding="20dip" android:textSize="25sp"/>
<ToggleButton android:layout_height="wrap_content"
    android:layout_width="match_parent"
    android:text="ToggleButton"
    android:id="@+id/toggleButton1"
    android:padding="20dip"></ToggleButton>
</LinearLayout>

```

Now, for the business logic. You should get the *Flashlight* parameters, then set the flash mode of the *Flashlight* to **"FLASH_MODE_TORCH"** to switch on, and reset the *Flashlight* to **FLASH_MODE_OFF** to switch off. Here's the code:

```

public class MainActivity extends Activity {
    Camera cam;
    ToggleButton mTorch;
    Parameters camParams;
    private Context context;
    AlertDialog.Builder builder;
    AlertDialog alertDialog;
    private final int FLASH_NOT_SUPPORTED = 0;
    private final int FLASH_TORCH_NOT_SUPPORTED = 1;
    /** Called when the activity is first created. */
    @Override
    public void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        setContentView(R.layout.main);
        context = MainActivity.this;
        if(context.getPackageManager().hasSystemFeature(
            PackageManager.FEATURE_CAMERA_FLASH)){
            mTorch = (ToggleButton) findViewById(R.
id.toggleButton1);

```




Figure 2: Alert Dialogue

Figure 3: Torch Demo (ON)

```

..... logic.....
else{
    showDialog(MainActivity.this, FLASH_NOT_SUPPORTED);
}

```

Now the first condition to check is whether the device has the flash feature; if yes, then proceed, else show an alert dialogue like in Figure 2. Then you get a reference to your *ToggleButton* using the *findViewById()* method.

```

mTorch.setOnCheckedChangeListener(new
OnCheckedChangeListener() {

    @Override
    public void onCheckedChanged(CompoundButton
buttonView, boolean isChecked) {

        try{
            if(cam != null){
                cam = Camera.open();
            }

            You then need to override the ToggleButton's
            onCheckedChanged method to handle state toggles. The
            Boolean parameter isChecked specifies whether the state
            is ON or OFF. Next, get hold of the camera object to
            access it:

            camParams = cam.getParameters();
            List<String> flashModes =
            camParams.getSupportedFlashModes();
            if(isChecked){
                if(flashModes.contains(
                    Parameters.FLASH_MODE_TORCH)) {
                    camParams.setFlashMode(
                        Parameters.FLASH_MODE_TORCH);
                }else{
                    showDialog(MainActivity.this,
                        FLASH_TORCH_NOT_SUPPORTED);
                }
            }else{
                camParams.setFlashMode(Parameters.FLASH_MODE_
OFF);
            }

```